



Tech Note

#135 Psychologist Wiring



[28 Oct 2002]

The following diagram shows all connections in the digital control chain for the Psychologist Personal Monitor Matrix. Please note that the PPS-12 should be installed as close to the stage area as possible to avoid significant voltage drop. A run of Cat 5 should be used between the matrix and the RJ12/DB9F adaptor. The PPS-12 should be tied to a good earth ground to avoid any static discharge related resets of the system.

