



## Tech Note

# Conflicting Mini-Mixers During the Discovery Process



[02/03/04]

In certain circumstances, mini-mixer addresses may temporarily conflict during the Psychologist remote discovery process. This conflict has been recognized--as long as the remotes are discovered in sequential order, the system will refresh itself and the mini-mixer addresses will be correctly identified and fully functional.

**However, if the mini-mixers are not discovered in sequential order--i.e., mini-mixer 11 is discovered before mini-mixer 1--the system will incorrectly refresh and incorrectly assign the mini-mixer addresses. This will render the latter mini-mixer inoperable.**

